

User's instruction

Video Eyewear



Anytime Anywhere Enjoy Movie & TV Freely!

- Please read the instruction before using this product for ensuring correct usage.

Thank you for buying the hi-tech
Video Eyewear!

Accessories:



Line control



Video Eyewear



Eyepatch



AV cable(1)



AV cable(2)



AV cable(3)

Earphone



USB charger



Nose pad



Remote





Introduction:

- Anytime, anywhere, enjoy movies & TV freely.
- 80 inch big screen(1M far), high-quality picture shown
- Unique optics design for safe and comfortable using.
- LCD display, no harm for eyes.
- Auto recognize and exchange between NTSC/PAL/SECAM
- Special design for glasses user with nose tongs.
- Connect to ipod video directly.
- Connect to cellphone , enjoy movie & TV.
- It can connect to any video which has AV output devices (iPod video, DVD, PMP, Game console, Playstation, Wii, Xbox, etc.)

Technology indexes:

Video Signal:	NTSC/PAL/SECAM
3D Format:	Stereoscopic Video Singnal
Display:	2 TFT LCD Displays
Color Depth:	24 Bit Input
Image Size:	80" Screen (1M far)
Resolution:	640x480(920K Pixels)
Audio:	double-channel stereo
Viewing Angle:	25° (Diagonal)
Battery:	1000mAH Lithium-ion battery (it is inside the Line Controller)
Charge Voltage:	DC5V
Net Weight:	59G (including earphones)
Power consumption:	<1.1W
Battery duration:	About 3.5 hours


Overview:



Operation Guide:

Example One:


- 1) Plug the AV input port of Video Eyewear into the AV output Port of ipod video directly as following draft.



- 2) Turn on the ipod video, find "Video setting" then select "TV out , set the mode" ON"
- 3) After set the ipod video, wear the Eyewear, then you can enjoy movies&TV.


Example Two:

- 1)The Video Eyewear matches with most any video or PC application. If the ports of devices do not match, then use the connectors for help. Such as RCA connector , please refer to the following draft.



- 2)Set "Video Setting" mode of MP4 or other video devices in the mode "Video out".
- 3)Video Eyewear is automatic switching on after receiving video signal.
- 4)After setting, you can enjoy your own cinema with Video Eyewear.

Charge as following draft:



- 1) Plug the pin of USB charger into adaptor port of video Eyewear, Connect the other port of USB charger to the USB port of computer, then video Eyewear can be charged.
- 2) Charge the eyewear in time while the power indication lamp flashing or out of power. The charge indication lamp lights on till charging completely. Please charge fully at the first usage for the best effects.
- 3) The Video eyewear matches with an exclusive Lithium-ion battery which can be fully charged within two hours while being completely discharged.
- 4) The Video eyewear can be charged under working or switching off.

Troubleshooting:

- The screen could not display image. How to do?

Three ways:

- 1)Please check the AV cable,shift the 3 ports till the Video Eyewear could be switched on.
 - 2)Please check the AV cable is properly connected.
 - 3)Please check the power and charge the Eyewear up in time.
- The user has myopic sight or hyperopic sight,how to use it?
For the Eyewear users,adjust the nose tongs for comfortable using with Video Eyewear

Other indexes:

- 1)Use the bander to fasten the Video eyewear.
- 2)Operation temperature:5~35 ° C
- 3)Storage temperature:-10~35 ° C



Warning!



- * Do not use unmatched adaptor at any time.
(It may cause the generation of abnormal heat or fire.)
- * Do not handle the power plug with wet hands for electric shock.
- * Using plug Properly and safely for fire.
- * Never disassemble or modify this product in any way.
- * Do not let any chemical materials connect with the product, ie: benzene, diluter, and etc..
- * Keep the product cleaning.
- * Keep the using ambient temperature between 5-35° C.
- * Do not drop or poud the product.
- * Keep the product away from a place where has severe vibration or a magnetic material.
- * Avoid using the product near a direct ray of light or heat -generating device, or has much moisture and smogbound.
- * Do not use the product while walking for safety
- * Dispose of used battery accor ding to local regulations. Recycle if possible. Never posting it into fire .Keep it away from children.
- * This product should not used by childen under the age of seven(7)

※If some content of this user's instruction are not consistent with products you bought, Our company has the right to explain.

- The products, specifications, and other content of this user's instruction are subject to change without notice.
- All rights reserved by our company.